## **Spotting Scope Operation Guide**

Thank you for purchasing an Oberwerk Spotting Scope! Our scopes are the very best value on the market, and are backed by Oberwerk's reputation for service and support. Operation is simple, here is what you need to get started.





## Assembly

The scope ships with a dust cover installed in the eyepiece socket. To remove, push down on the eyepiece release tab (shown upper left) and twist the cover to the left to remove. To install the zoom eyepiece, line up the white dot on the eyepiece with the white arrow on the scope (shown upper right). Insert eyepiece and twist right until it clicks.

## Operation

If wearing glasses, leave the twist-up eyecup in the down position. If not wearing glasses, twist eyecup left to raise it up. To start, rotate the zoom ring to the lowest magnification (15x or 20x depending on model). While looking through the eyepiece at a distant scene, turn the course focus knob until focus looks reasonably sharp. Then turn the fine focus knob until sharpest focus is obtained. Rotate zoom ring to desired magnification. Slight fine focus adjustment may be needed when changing magnification. Excess glare from the sun? Simply extend the glare shield.



Oberwerk 20-60x82 Sport ED components and controls

## Support

Questions? Please call or email, we're standing by, ready to help!



1861 Wayne Ave., Dayton, Ohio 45410 USA https://www.oberwerk.com 937-640-1040 support@oberwerk.com